

Split-Phase Capacitor Start AC Motor Training System



Model: 410-000

AC electric motors are found in a wide variety of industrial, commercial, and residential applications. Industrial maintenance technicians must develop industry-relevant skills, such as how to operate, install, design, and troubleshoot AC electric motor control circuits for various applications.

DAC Worldwide's Split-Phase Capacitor Start AC Motor Training System (410-000) features a common split phase, capacitor start AC motor used frequently throughout industry. Each motor module includes a welded aluminum mounting baseplate, aluminum control box support structure, and a steel control enclosure.

All motor wiring is accomplished through banana jack receptacles on the control enclosure's front panel face. Each unit comes equipped with an appropriate voltmeter and ammeter. In addition, four instructor fault insertion switches are provided on each motor module.

The Split-Phase Capacitor Start AC Motor Training System requires the following items:

- #410-001E Economy Portable Multimeter
- #410-002 Non-Contact Tachometer Kit
- #410-100 Prony Brake Assembly

Industry-Standard Components Provide Realistic, Hands-On Training

Technical training is most effective when learners can gain hands-on practice with industry-standard components they'll encounter on the job. The Split-Phase Capacitor Start AC Motor Training System features a wide variety of common, industrial-quality components to provide learners with a realistic training experience that will build skills that translate easily to the workplace.

The Split-Phase Capacitor Start AC Motor Training System is a sturdy unit that features industrial-quality

components, such as: AC motor mounted on T-slotted rails; master circuit breaker with lock-out/tag-out capability; color-coded banana jack patch cord receptacles; voltmeter; ammeter; enclosure cover safety interlock switch; 4 instructor fault insertion switches; large emergency stop switch; large pilot light; and keyed instructor power switch.

Courseware & Hands-On Exercises

The Split-Phase Capacitor Start AC Motor Training System's courseware consists of a textbook on motors and motor control, instructor and student wiring diagrams, and a Use/Exercise Guide with hands-on exercises. These can be used as part of either an instructor-led course or self-directed study.

Learners will explore a wide variety of fundamental motor control topics, including: motor control terminology and construction; motor nameplate data; and AC motor troubleshooting. Hands-on exercises include industry-relevant motor control skills, such as wiring and troubleshooting the split phase, capacitor start AC motor.

Expand Training Capabilities with Custom Options

The Split-Phase Capacitor Start AC Motor Training System can be customized with a variety of options to create a training system that matches a particular industry's or user's specific needs. In industry, one size rarely fits all and this trainer can be tailor-made to your exact needs.

For example, training capabilities can be expanded by adding the following available options: motor loading module; and instructional videos, handbooks, and training manuals.

FEATURES & SPECIFICATIONS

- Service requirements: Electric: 110 VAC - 240 VAC, 3-phase, based on individual product.
- Welded aluminum baseplate.
- Provision for bench-top mounting.
- Motors mounted on T-slotted rails which accommodate 184T and 56 frame motors (56 frame standard).
- Master circuit breaker with lock-out/tag-out capability.
- Silkscreened panel face with identification of line and motor lead numbers.
- Color-coded banana-jack patch cord receptacles.
- Voltmeter and ammeter.
- Permanent internal grounding of all elements.
- Enclosure cover safety interlock switch.
- Four instructor fault insertion switches (on rear of control enclosure).
- Large emergency stop switch.
- Keyed instructor power switch (on rear of control enclosure).

- Large pilot light.
- Use of UL and CE certified electrical components throughout.
- Patch cords.
- Use/Exercise Guide.
- Instructor and student wiring diagrams.
- Related textbook (with purchase of four or more devices).
- Packaging for shipment via motor freight.

PRODUCT DIMENSIONS **DISCLAIMER:** *Product Dimensions are approximate. Shipping Dimensions and Weights are for directional use only and may change based on manufacturer variables. For the most accurate Shipping Dimensions and Weights, please contact the manufacturer.*

- **Product Dimensions**
(L x W x H)
Approx. 19in. x 19in. x 25in. (480 x 480 x 640 mm)
50lbs. (23kg)
- **Shipping Dimensions**
Approx. 85lbs. (39kg)

OPTIONS

- #410-001 - Portable digital multimeter
- #410-001E - Portable Multimeter, Economy. (required)
- #410-002 - Non-Contact Tachometer. (required)
- #410-100 - Prony Brake Assembly. (required)
- #410-500 - Use/Exercise Guide (additional)
- #560-000 - Electrical Trades Training Manual (IPT)
- #560-001 - Electrical Trades Handbook (IPT)

Address

DAC Worldwide
601 Heron Drive
Swedesboro, NJ 08085

Contacts

email: contact@dacworldwide.com
phone: (800) 662 5877